

8 Kilowatts Inverter

# **USER MANUAL**


































# **Table Of Contents**

1	ABOUT THIS MANUAL	3
1.		
1.2		
2	SAFETY INSTRUCTIONS	3
3	INTRODUCTION	4
3.	1 FEATURES	4
3.2		
3.3		
4	INSTALLATION	6
4.	1 Unpacking and Inspection	6
4.2		
4.3	3 MOUNTING THE UNIT	6
4.4	4 BatteryConnection	6
4.5	5 AC INPUT/OUTPUT CONNECTION	8
4.0	6 PV CONNECTION	9
4.′	7 Final Assembly	11
4.8	8 COMMUNICATION CONNECTION	11
5	OPERATION	11
5.	1 Power ON/OFF	11
5.2	2 OPERATION AND DISPLAY PANEL	11
5.3	3 LCD DISPLAY ICONS	12
5.4	4 LCD Setting	14
5.3	5 DISPLAY SETTING	21
5.0	6 OPERATING MODE DESCRIPTION	25
5.	7 BATTERY EQUALIZATION DESCRIPTION	26
5.8	8 FAULT REFERENCE CODE	27
5.9	9 Warning Indicator	28
6	CLEARANCE AND MAINTENANCE FOR ANTI-DUST KIT	29
6.	1 Overview	29
6.2	2 CLEARANCE AND MAINTENANCE	29
7	SPECIFICATIONS	30
TA	ABLE 1 LINE MODE SPECIFICATIONS	31
TA	ABLE 2 INVERTER MODE SPECIFICATIONS	32
TA	ABLE 3 CHARGE MODE SPECIFICATIONS	33
	ABLE 4 Grid-Tie Operation	
	ABLE 5 GENERAL SPECIFICATIONS	
8	TROUBLE SHOOTING	33
9	APPENDIX: APPROXIMATE BACK-UP TIME TABLE	34

#### 1 ABOUT THIS MANUAL

#### 1.1 Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

#### 1.2 Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

#### **2 SAFETY INSTRUCTIONS**



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- 1. Before using the unit, read all instructions and cautionary markings on the unit, the batteries and all appropriate sections of this manual.
- 2. **CAUTION** --To reduce risk of injury, charge only deep-cycle lead acid type rechargeable batteries. Other types of batteries may burst, causing personal injury and damage.
- 3. Do not disassemble the unit. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
- 4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- 5. **CAUTION** Only qualified personnel can install this device with battery.
- 6. **NEVER** charge a frozen battery.
- 7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter/charger.
- 8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
- 9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
- 10. One piece of 150A fuse is provided as over-current protection for the battery supply.
- 11. GROUNDING INSTRUCTIONS -This inverter/charger should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- 12. NEVER cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
- 13. **Warning!!** Only qualified service persons are able to service this device. If errors still persist after following troubleshooting table, please send this inverter/charger back to local dealer or service center for maintenance.

#### 3 INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

#### 3.1 Features

- Pure sine wave inverter
- □ Configurable input voltage range for home appliances and personal computers via LCD setting
- □ Configurable battery charging current based on applications via LCD setting
- □ Configurable AC/Solar Charger priority via LCD setting


- Overload/ Over temperature/ short circuit protection
- Cold start function

#### 3.2 Basic System Architecture


The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- □ Generator or Utility.

Consult with your system integrator for other possible system architectures depending on your requirements. This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.



#### 3.3 Product Overview



- 1. LCD display
- 2. Status indicator
- 3. Charging indicator
- 4. Fault indicator
- 5. Touch Function buttons
- 6. Power on/off switch
- 7. AC input
- 8. Main output
- 9. Second output
- 10. PV1 and PV2 input
- 11. RS-232/WIFI/Remove LCD communication port
- 12. Battery input
- 13. Anti dust kit

#### **4 INSTALLATION**

#### 4.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:


- ☐ The unit x 1
- □ User manual x 1
- □ DC Fuse x 1
- □ Ring terminal x 1
- 4.2 Preparation

Before connecting all wirings, please take off bottom cover by removing two screws as shown below.

#### 4.3 Mounting the Unit

Consider the following points before selecting where to install:

- ₩ Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- \* Install this inverter at eye level in order to allow the LCD display to be read at all times.
- # For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 50 cm above and below the unit.
- $\mbox{\ensuremath{\mathfrak{H}}}$  The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- \( \mathbb{H} \) The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.





#### SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing two screws. It's recommended to use M4 or M5 screws.

#### 4.4 Battery Connection

**CAUTION:** For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

**WARNING!** All wiring must be performed by a qualified personnel.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable as below.

#### Recommended battery cable size:


Model	Wire Size	Cable (mm²)	Torque value (max)
PV 9200/PV 12200	1 x 2AWG	25	2 Nm

Please follow below steps to implement battery connection:

- 1. Remove insulation sleeve 18 mm for positive and negative conductors.
- 2. Suggest to put bootlace ferrules on the end of positive and negative wires with a proper crimping tool.




3. Connect all battery packs as below chart.



4. Insert the battery wires flatly into battery connectors of inverter and make sure the bolts are tightened with torque of 2 Nm in clockwise direction. Make sure polarity at both the battery and the inverter/charge is correctly connected and conductors are tightly screwed into the battery terminals.

Recommended tool: #2 Pozi Screwdriver





#### **WARNING: Shock Hazard**

Installation must be performed with care due to high battery voltage in series.



**CAUTION!!** Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

#### 4.5 AC Input/Output Connection

**CAUTION!!** Before connecting to AC input power source, please install a **separate** AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 63A for PV 9200/PV 12200.

**CAUTION!!** There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

**WARNING!** All wiring must be performed by a qualified personnel.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

#### Suggested cable requirement for AC wires

Model	Gauge	Cable (mm²)	Torque Value
PV 9200/PV 12200	10 AWG	6	1.2 Nm


Please follow below steps to implement AC input/output connection:

- 1. Before making AC input/output connection, be sure to open DC protector or disconnector first.
- 2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3 mm.
- 3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor ( ) first.

Ground (yellow-green)

L→LINE (brown or black)

N→Neutral (blue)






#### **WARNING:**

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.


L→LINE (brown or black) N→Neutral (blue)



4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.

L→LINE (brown or black)

N→Neutral (blue)



5. Make sure the wires are securely connected.

**CAUTION:** Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

#### 4.6 PV Connection

**CAUTION:** Before connecting to PV modules, please install **separately** a DC circuit breaker between inverter and PV modules.

**WARNING!** It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Size	Cable (mm²)	Torque value (max)
PV 9200/PV 12200	1 x 10AWG	6	1.2 Nm

#### **PV Module Selection:**

When selecting proper PV modules, please be sure to consider below parameters:

- 1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
- 2. Open circuit Voltage (Voc) of PV modules should be higher than min. battery voltage.

INVERTER MODEL	PV 9200 PV 12200	
Max. PV Array Open Circuit Voltage	500Vdc	
PV Array MPPT Voltage Range	90Vd	c~450Vdc

Take 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed as below table.

Solar Panel Spec.	SOLAR INPUT	Q'ty of panels	Total input
(reference) - 250Wp	(Min in serial: 6 pcs, max. in serial: 13 pcs)	Q ty or pariets	power
- Vmp: 30.1Vdc	6 pcs in serial	6 pcs	1500W
- Imp: 8.3A	8 pcs in serial	8 pcs	2000W
- Voc: 37.7Vdc	12 pcs in serial	12 pcs	3000W
- Isc: 8.4A	13 pcs in serial	13 pcs	3250W
- Cells: 60	12 pieces in serial and 3 sets in parallel	36 pcs	8200W
	10 pieces in serial and 4 sets in parallel	40 pcs	10200W

#### **PV Module Wire Connection**

Step 1: Check the input voltage of PV array modules. The acceptable input voltage of the inverter is 120VDC - 500VDC. Please make sure that the maximum current load of each PV input connector is 10A.



**CAUTION:** Exceeding the maximum input voltage can destroy the unit!! Check the system before wire connection.

#### Step 2: Disconnect the DC circuit breaker.


Step 3: Assemble provided PV connectors with PV modules by the following below steps.

#### Components for PV connectors and Tools:

Female connector housing	Male terminal	
Female terminal	 Crimping tool and spanner	
Male connector housing		

#### Cable preparation and connector assembly process:

Strip one cable 8 mm on both end sides and be careful NOT to nick conductors.



Insert striped cable into female terminal and crimp female terminal as shown below charts.



Insert assembled cable into female connector housing as shown below charts.




Insert striped cable into male terminal and crimp male terminal as shown below charts.



Insert assembled cable into male connector housing as shown below charts.



Then, use spanner to screw pressure dome tightly to female connector and male connector as shown below. Step 4: Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.



#### 4.7 Final Assembly

After connecting all wirings, please put bottom cover back by screwing two screws as shown below.

#### 4.8 Communication Connection

#### 1. Wi-Fi cloud communication (option):

Please use supplied communication cable to connect to inverter and Wi-Fi module. Download APP and installed from APP store, and Refer to "Wi-Fi Plug Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or webpage of computer.

#### 2. GPRS cloud communication (option):

Please use supplied communication cable to connect to inverter and GPRS module, and then applied external power to GPRS module. Download APP and installed from APP store, and Refer to "GPRS RTU Quick Installation Guideline" to set up network and registering. The inverter status would be shown by mobile phone APP or webpage of computer.

## RGB Light (option)


1 Battery Mode:red Light

2 Utility Mode:blue Light

③ PV Mode:purple Light

#### 5 OPERATION

#### 5.1 Power ON/OFF




Once the unit has been properly installed and the batteries are connected well, simply press On/Off switch (located on the button of the case) to turn on the unit.

#### 5.2 Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.





LCD display

### **LED Indicator**

LED Indicator			Messages
	Green	Solid On	Output is powered by utility in Line mode.
INV/AC 📮	Green	Flashing	Output is powered by battery or PV in battery mode.
cuc •	Green	Solid On	Battery is fully charged.
CHG A		Flashing	Battery is charging.
FALLET A	ILT A Red		Fault occurs in the inverter.
PAULI #			Warning condition occurs in the inverter.

## **Function Keys**

Function Key	Description			
ESC	To exit setting mode			
UP To go to previous selection				
DOWN To go to next selection				
ENTER	To confirm the selection in setting mode or enter setting mode			

## 5.3 LCD Display Icons



Icon	Function description					
Input Source Inf	Input Source Information					
	Indicates the AC input.					
	Indicates the PV input					
BBB kw v hz a	Indicate input voltage, input frequency, PV voltage, charger current (if PV in charging for PV 9200 models), charger power, battery voltage.					

Configuration Pr	ogram and Fault Information		
(8.8.8)	Indicates the setting programs.		
	Indicates the warning and fault codes.		
	Warning: <b>B.B.8</b> flashing with warning code.		
	Fault: <b>B.B.B.</b> lighting with fault code		
Output Informati			
BBB KW VA %	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.		
<b>Battery Informat</b>	ion		
Load Information	1		
OVERLOAD	Indicates overload.		
Mode Operation	Information		
	Indicates unit connects to the mains.		
	Indicates unit connects to the PV panel.		
AC BYPASS	Indicates load is supplied by utility power.		
<u>\$</u>	Indicates the utility charger circuit is working.		
<u>\$</u>	Indicates the DC/AC inverter circuit is working.		
<b>Mute Operation</b>			
⊀×	Indicates unit alarm is disabled.		

#### 5.4 LCD Setting

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

## **Setting Programs:**

	Programs:		
Program	Description	Selectable option	
00	Exit setting mode	Escape (default)	One-button restore setting options
		00 <u>60H</u>	
		Utility first	Utility will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when utility power is not available.
01	Output source priority: To configure load power source priority	Solar first (default)	Solar energy provides power to the loads as first priority.  If solar energy is not sufficient to power all connected loads, utility will supply power to the loads at the same time.  Battery provides power to the loads only when any one condition happens:  - Solar energy and utility is not available.  - Solar energy is not sufficient and utility is not available.
		SBU priority	Solar energy provides power to the loads as first priority.  If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time.  Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.
		MKS priority  I h 5	Solar energy provides power to the loads as frist priority, if solar energy is not sufficient to power all connected loads, utility energy will supply power to the loads at the same time. The battery only supplies energy to the load as a backup power.
02	Maximum charging current: To configure total charging current for solar and utility chargers.	10A 02 <u>10^</u>	<sup>20A</sup> 20 <sup>^</sup>
32	(Max. charging current = utility charging current + solar charging current)	02 <u>30 v</u>	40A 02 <u>40^</u>

	50A 02	50 ^ 02	efault)	70A 02_	<u> 70 ^</u>
02	02 02	80, 05	90^	100A 02	<u>100 ^</u>
02	110A 02_	110^ 02	120^	130A 02	30 <u>^</u>   140 A 30 <u>^</u>   140 A
	150A 02_	150 ^ 160A 02_	<u>160^</u>		
02	AC input valtage range	Appliances (default	\		cceptable AC input e will be within
03	AC input voltage range	03 UPS	\	•	cceptable AC input e will be within
		AGM (default)	F	-looded 05_F(	_d_
05	Battery type	User-Defined USE USE	l t	If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.	
		User-Defined L16	V i· v	Vhen the sola tem to LIB, an	r energy exists,Set this d the lithiumbattery ed for 3 second.
06	Auto restart when overload occurs	Restart disable (de	fault) F	Restart enab	le - <u>E</u>
07	Auto restart when over temperature occurs	Restart disable (de	fault) F	Restart enab	le - <b>E</b>
09	Output frequency	50Hz (default)		50Hz ]9{	50 <sub>Hz</sub>
10	Output voltage	10 220v	2	230V (defaul	
	Carpat rollage	240V 10 240°			
	Maximum utility charging current	1	10A	108	20A 
11	Note: If setting value in program 02 is smaller than that in program in 11, the inverter will apply charging	30A (default)	40A	40A	50A 

	current from program 02 for utility charger.	60A	50A	70A     	70R	80A     8	OR.	-
		90A       -	90R	100A	100R	110A 	OR.	120A 
		130A	130A_	140A	140A	_		
		Availal 42V	ole options ir	PV 9:	200/PV 122 43V	00 model:	44V	
		12	BATT 	_	12_	ватт В ч	15	BATT V
		45V			46V (defa	ult)	47V	
12	Setting voltage point back to utility source when selecting "SBU priority" or	15	HSv	_	15_	H <sub>6</sub> ′	12	BATT V
	"Solar first" in program 01.	48V			49\	/	1	
		15	HB <sup>v</sup>	_	lā	D HATT	<u>9</u> ′	
		50V			51\			
		15	SO <sub>v</sub>		lā	5	ļv_	
			ole options ir y fully charge		200/PV 122 48V	00 <b>model:</b>		
	Sotting voltage point back	13	FUL	- -	13_	HBV	_	
13	Setting voltage point back to battery mode when selecting "SBU priority" or "Solar first" in program 01.	49V			50V			
		13_	YS. V	_	13_	50.0°	-	
		51V			52V			
		13_	5 10	_	13_	SCO <sub>v</sub>	_	
		53V	2477		54V (det			
		13	530	_	13_	5 <u>40</u> ,	_	

		55V 56V	1	
		13 <u>550</u>	3 <u>56.0 °</u>	
		57V 58V	'	
			3 <u>580°</u>	
		If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:		
		Solar first  15	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.	
16	Charger source priority: To configure charger source priority	Solar and Utility (default)	Solar energy and utility will charge battery at the same time.	
		Only Solar	Solar energy will be the only charger source no matter utility is available or not.	
		If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will		
		charge battery if it's available	and sufficient.	
18	Alarm control	Alarm on (default)	Alarm off 18 60F	
19	Auto return to default display screen	Return to default display screen (default)	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.	
		Stay at latest screen	If selected, the display screen will stay at latest screen user finally switches.	
20	Backlight control	Backlight on (default)	Backlight off 20 LOF	

22	Beeps while primary source	Alarm on (default)	Alarm off	
22	is interrupted	55 <u>800</u>	55 <u>80F</u>	
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default)	Bypass enable	
25	Record Fault code	Record enable (default)	Record disable	
26	Bulk charging voltage (C.V voltage)	PV 9200/PV 12200 default setting: 56.4V  Lucido 26 564  If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 61.0V for PV 9200/PV 12200 model. Increment of each click is 0.1V.		
27	Floating charging voltage		rogram 5, this program can be set V to 61.0V for PV 9200/PV 12200	
29	Low DC cut-off voltage	If self-defined is selected in prup. Setting range is from 40.0 model. Increment of each click	rogram 5, this program can be set by to 48.0V for PV 9200/PV 12200 k is 0.1V. Low DC cut-off voltage will tter what percentage of load is	

		Battery equalization	Battery equalization disable (default)	
30	Battery equalization	RN <u>66U</u>	30 <u>885</u>	
	, ,	If "Flooded" or "User-Defi	ned" is selected in program 05, this	
		program can be set up.		
		PV 9200/PV 12200 <b>default</b> :	setting: 58.4V	
		բս 3¦ գ	MATT	
			<u>U. T</u>	
31	Battery equalization voltage	Setting range is from 48.0	OV to 61.0V for PV 9200/PV 12200	
		model. Increment of each	n click is 0.1V.	
		60min (default)	Setting range is from 5min to 900min.	
33	Battery equalized time	33 60	Increment of each click is 5min.	
		<u> </u>		
		120min (default)	Setting range is from 5min to 900 min.	
34	Battery equalized timeout	34  20	Increment of each click is 5 min.	
		30days (default)	Setting range is from 0 to 90 days.	
35	Equalization interval		Increment of each click is 1 day	
		22 <u>309</u>		
		Enable	Disable (default)	
	Equalization activated immediately	36 RFN	136 RAS	
36		If equalization function is enabled in program 30, this program can be set up. If "Enable" is selected in this program, it's to activate		
30		battery equalization immediately and LCD main page will shows		
		"Eq". If "Disable" is selected, it will cancel equalization function		
		until next activated equalization time arrives based on program 35		
			" will not be shown in LCD main page.	
	GRID-tie operation	Off grid (default)	Inverter operates only in off-grid	
37		7] UEE	mode. Solar energy provides power to the loads as first priority and charging	
			second	
		Hybrid	Inverter operates hybrid mode. Solar	
		-   - 	energy provides power to the loads as	
		j	first priority and charging second	
			Excess energy feed to grid.	


38	GRID-tie current	10A 38 <u>  0</u> ^	Increment of each click is 2A.	
39	Led pattern light	Led pattern off  39 LOF	Led pattern on(default)  39 LON	
41	Dual output	disable (default)	use 41 <u>20</u>	
42	Enter the dual output functional voltage point	PV 9200/PV 12200 default s	setting: 44.0V	
		Setting range is from 40.0V to 46.0V for 48VDC model.  Increment of each click is 0.1V.		

## 5.5 Display Setting


The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, charging current, charging power, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DC discharging current, main CPU Version.

Selectable information	LCD display			
Charged state, and the power is less than 1kw				
Input voltage=222V, PV voltage=168V, Battery voltage=25V, Output voltage=222V, Load in Watt=188W, Chg(Flashing), Inv/ac(bright)	GRID  LOAD  BBB  V Hz A C  KW VA %  BINVIAC ECHG  SOLAR  BATTERY			
Input voltage=223V, PV current=2.3A, Battery current=20A, Output voltage=224V, Load in VA=188VA, Chg(Flashing), Inv/ac(bright)	SOLAR S LOAD  LOAD  LOAD  LOAD  A SOLAR S LOAD  A BATTERY			

Input voltage=223V,
Pv ntc temperture=71.0°C,
Battery voltage=25V,
Inv ntc temperture=35.0°C,
Load percentage=12%,
Chq(Flashing), Inv/ac(bright)




Input frequency=50.0Hz, PV power=0.434KWh, Battery current=20A, Output frequency=50.0Hz, Load in watt=188W, Chg(Flashing), Inv/ac(bright)




### Charged state, and the power is greater than 1kw


Input voltage=222V, PV voltage=168V, Battery voltage=25V, Output voltage=222V, Load in Watt=1.18KW, Chg(Flashing), Inv/ac(bright)




Input voltage=224V, PV current=8.6A, Battery current=12.5A, Output voltage=222V, Load in VA=1.88KVA, Chg(Flashing), Inv/ac(bright)




Input voltage=223V,
Pv ntc temperture=71.0°C,
Battery voltage=25V,
Inv ntc temperture=35.0°C,
Load percentage=82%,
Chg(Flashing), Inv/ac(bright)



Input frequency=50.0Hz, PV power=1.434KWh, Battery current=20A, Output frequency=50.0Hz, Load in watt=1.88KW, Chg(Flashing), Inv/ac(bright)



## Discharged state, and the power is less than 1kw Input voltage=0V, 255 PV voltage=0V, Battery voltage=25V, Output voltage=222V, Load in Watt=188W, Chq(turn off), Inv/ac(Flashing) Input voltage=0V, 555 PV current=0A, Battery current=12.5A, Output voltage=222V, Load in VA=188VA, Chg(turn off), Inv/ac(Flashing) Input voltage=0V, Pv ntc temperture=60.0°C, 36.0 Battery voltage=24V, Inv ntc temperture=36.0°C, 600 i Load percentage=13%, Chg(turn off), Inv/ac(Flashing) Input frequency=0Hz, 188 PV power=0KWh, Battery current=12A, Output frequency=50.0Hz, Load in watt=188W, Chg(turn off), Inv/ac(Flashing)



## 5.6 Operating Mode Description

Operation mode	Selectable information	LCD display
	Input voltage=222V, PV voltage=210V, Battery voltage=25V, Output voltage=0V, Load in Watt=0W, Chg(Flashing), Inv/ac(bright)	GRID 1 PERMISS 222 W D D D D D D D D D D D D D D D D D
Stanby mode	Input voltage=223V, PV voltage=0V, Battery voltage=25V, Output voltage=0V, Load in Watt=0W, Chg(Flashing), Inv/ac(bright)	GRID 1 2 LOAD  W D PROPERTY  W D PROPERTY  W D PROPERTY  SOLAR B ATTERY
·	Input voltage=0V, PV voltage=210V, Battery voltage=25V, Output voltage=0V, Load in Watt=0W, Chg(Flashing)	GRID  LOAD  W  LINVIAC BCHG  SOLAR  BATTERY
	Input voltage=224V, PV current=8.6A, Battery current=12.5A, Output voltage=222V, Load in VA=1.88KVA, Chg(Flashing), Inv/ac(bright)	GRID  224  222  BB  WVA  BATTERY  BATTERY
Line mode	Input voltage=224V, PV voltage=0V, Battery voltage=25V, Output voltage=222V, Load in Watt=188W, Chg(Flashing), Inv/ac(bright)	GRID  224  222  W  BATTERY  SOLAR  BATTERY
Grid-Tie Operation	Input voltage=224V, PV current=8.6A, Battery current=12.5A, Output voltage=222V, Load in VA=1.88KVA, Chg(Flashing), Inv/ac(bright)	When working in Grid-Tie mode, the will be flash 3S/times.

Operation mode	Selectable information	LCD display
Dattamanda	Input voltage=0V, PV voltage=180V, Battery voltage=25V, Output voltage=230V, Load in Watt=388W, Inv/ac(Flashing)	GRID  ACERTSAS  ACERTSAS
Battery mode	Input voltage=0V, PV voltage=180V, Battery voltage=25V, Output voltage=230V, Load in Watt=388W, Chg(Flashing), Inv/ac(Flashing)	GRID  LOAD  BRAVAC SICHS  BATTERY  BATTERY

#### 5.7 Battery Equalization Description

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.


#### **∺** How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 30 first. Then, you may apply this function in device by either one of following methods:

- 1. Setting equalization interval in program 35.
- 2. Active equalization immediately in program 36.


#### **₩ When to Equalize**

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




#### **#** Equalize charging time and timeout

In Equalize stage, the controller will supply power to charge battery as much as possible until battery voltage raises to battery equalization voltage. Then, constant-voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.



However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized timeout setting is over, the charge controller will stop equalization and return to float stage.



#### 5.8 Fault Reference Code

Fault Code	Fault Event	Icon on
01	Fan is locked when inverter is off.	☐ I ERROR
02	Over temperature	02 ERROR
03	Battery voltage is too high	03 ERROR
04	Battery voltage is too low	04 ERROR
05	Output short circuited or over temperature is detected by internal converter components.	OS ERROR
06	Output voltage is too high.	06 ERROR
07	Overload time out	ERROR
08	Bus voltage is too high	08 error
09	Bus soft start failed	09 ERROR
51	Over current or surge	5 I ERROR

52	Bus voltage is too low	52 ERROR
53	Inverter soft start failed	53 <sub>error</sub>
55	Over DC voltage in AC output	55 ERROR
57	Current sensor failed	57 <sub>error</sub>
58	Output voltage is too low	58 <sub>error</sub>
59	PV voltage is over limitation	59 <sub>error</sub>

## 5.9 Warning Indicator

Warning Code	Warning Event	Audible Alarm	Icon flashing
01	Fan is locked when inverter is on.	Beep three times every second	
03	Battery is over-charged	Beep once every second	
04	Low battery	Beep once every second	04 <b>®</b>
07	Overload	Beep once every 0.5 second	
10	Output power derating	Beep twice every 3 seconds	[] <b>©</b>
15	PV energy is low.	Beep twice every 3 seconds	
<i>E9</i>	Battery equalization	None	
<b>ЬР</b>	Battery is not connected	None	6P <b>®</b>


#### **6 CLEARANCE AND MAINTENANCE FOR ANTI-DUST KIT**

#### 6.1 Overview


Every inverter is already installed with anti-dusk kit from factory. Inverter will automatically detect this kit and activate internal thermal sensor to adjust internal temperature. This kit also keeps dusk from your inverter and increases product reliability in harsh environment.

#### 6.2 Clearance and Maintenance

**Step 1:** Please loosen the screw in counterclockwise direction on the top of the inverter.



Step 2: Then, dustproof case can be removed and take out air filter foam as shown in below chart.



**Step 3:** Clean air filter foam and dustproof case. After clearance, re-assemble the dust-kit back to the inverter.

**NOTICE:** The anti-dust kit should be cleaned from dust every one month.

## **SPECIFICATIONS**

Table 1 Line Mode Specifications

INVERTER MODEL	PLATINUM 9200-48	PLATINUM 12200-48	
Input Voltage Waveform	Sinusoidal (utility or generator)		
Nominal Input Voltage	230Vac		
Low Loss Voltage	170Vac±7	` ''	
	90Vac±7V (/		
Low Loss Return Voltage	180Vac±7 100Vac±7V (	` '	
High Loss Voltage	280Va	c±7V	
High Loss Return Voltage	270Vac±7V		
Max AC Input Voltage	300Vac		
Nominal Input Frequency	50Hz / 60Hz (Auto detection)		
Low Loss Frequency	40±1Hz		
Low Loss Return Frequency	42±1Hz		
High Loss Frequency	65±1Hz		
High Loss Return Frequency	63±1Hz		
Output Short Circuit Protection	Circuit Breaker		
Efficiency (Line Mode)	>95% ( Rated R load, battery full charged )		
Transfer Time	10ms typical (UPS); 20ms typical (Appliances)		
Output power derating: When AC input voltage drops to 170V, the output power will be derated.	Output Power  Rated Power  50% Power  90V 170V 280V Input Voltage		

Table 2 Inverter Mode Specifications

INVERTER MODEL	PLATINUM 9200-48	PLATINUM 12200-48
Rated Output Power	8.2KW	10.2KW
Output Voltage Waveform	Pure Sine Wave	
Output Voltage Regulation	230Vac±5%	
Output Frequency	50Hz	
Peak Efficiency	93%	
Overload Protection	3s@≥150% load; 5s@101%~150% load	
Surge Capacity	2* rated power for 5 seconds	
Nominal DC Input Voltage	48Vdc	
Cold Start Voltage	46.0Vdc	
Low DC Warning Voltage		
@ load < 50%	44.0Vdc	
@ load ≥ 50%	42.0Vdc	
Low DC Warning Return Voltage		
@ load < 50%	45.0Vdc	
@ load ≥ 50%	44.0Vdc	
Low DC Cut-off Voltage		
@ load < 50%	41.0Vdc	
@ load ≥ 50%	40.0Vdc	
High DC Recovery Voltage	62Vdc	
High DC Cut-off Voltage	63Vdc	
No Load Power Consumption	70W 75W	

Table 3 Two Load Output Power

INVERTER MODEL	PLATINUM 9200-48	PLATINUM 12200-48
Full Load	8200W	10200W
Maximum Main Load	8200W	10200W
Maximum Second Load(battery model)	2733W	3400W
Main Load Cut Off Voltage	44VDC	
Main Load Return Voltage	52VDC	

Table 4 Charge Mode Specifications

Utility Charging Mode			
INVERTER MODEL		PLATINUM 9200-48	PLATINUM 12200-48
Charging Algor	rithm	3-S	tep
AC Charging Co	urrent (Max)	140Amp	140Amp
<b>Bulk Charging</b>	Flooded Battery	58	.4
Voltage	AGM / Gel Battery	56	.4
Floating Charging Voltage		54\	/dc
Charging Curve	harging Curve		
MPPT Solar Cha			
INVERTER MOD	DEL	PLATINUM 9200-48	PLATINUM 12200-48
Max. PV Array I	Power	8200W	10200W
Nominal PV Vol	ltage	360Vdc	
PV Array MPPT	Voltage Range	90Vdc~500Vdc	
Max. PV Array	Open Circuit Voltage	500Vdc	
Max Charging ( (AC charger plu	Current Is solar charger)	160Amp 160Amp	

Table 5 Grid-Tie Operation

INVERTER MODEL	PLATINUM 9200-48	PLATINUM 12200-48
Nominal Output Voltage	220/230/240 VAC	
Feed-in Grid Voltage Range	195 ~ 253VA C	
Feed-in Grid Frequency Range	49~51±1Hz/59~61±1Hz	
Nominal Output Current	35.6A 44.3A	
Power Factor Range	>0.99	
Maximum Conversion Efficiency (DC/AC)	98%	

## Table 6 General Specifications

INVERTER MODEL	PLATINUM 9200-48	PLATINUM 12200-48
Safety Certification	CE	
Operating Temperature Range	-10°C to 50°C	
Storage temperature	-15°C~ 60°C	
Humidity	5% to 95% Relative Humidity (Non-condensing)	
Dimension (D*W*H), mm	500*390*130mm	530*390*130mm
Net Weight, kg	14.2	14.5

## **8 TROUBLE SHOOTING**

Problem	LCD/LED/Buzzer	Explanation / Possible cause	What to do	
Unit shuts down automatically during startup process.	LCD/LEDs and buzzer will be active for 3 The battery voltage is too low seconds and then complete off.		Re-charge battery.     Replace battery.	
No response after power on.	No indication.	The battery voltage is far too low. (<1.4V/Cell)     Internal fuse tripped.	<ol> <li>Contact repair center for replacing the fuse.</li> <li>Re-charge battery.</li> <li>Replace battery.</li> </ol>	
	Input voltage is displayed as 0 on the LCD and green LED is flashing.	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.	
Mains exist but the unit works in battery mode.	Green LED is flashing.	Insufficient quality of AC power. (Shore or Generator)	<ol> <li>Check if AC wires are too thin and/or too long.</li> <li>Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS♠ Appliance)</li> </ol>	
	Green LED is flashing.	Set "Solar First" as the priority of output source.	Change output source priority to Utility first.	
When the unit is turned on, internal relay is switched on and off repeatedly.	LCD display and LEDs are flashing	Battery is disconnected.	Check if battery wires are connected well.	
	Fault code 07	Overload error. The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.	
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.	
		Temperature of internal converter component is over 120°C.	Check whether the air flow of the unit is blocked or whether	
	Fault code 02	Internal temperature of inverter component is over 100°C.	the ambient temperature is too high.	
	Fault code 03	Battery is over-charged.	Return to repair center.	
Buzzer beeps continuously and red LED is on.		The battery voltage is too high.	Check if spec and quantity of batteries are meet requirements.	
	Fault code 01	Fan fault	Replace the fan.	
	Fault code 06/58	Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac)	Reduce the connected load.     Return to repair center	
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.	
	Fault code 51	Over current or surge.	Restart the unit, if the error happens again, please return	
	Fault code 52	Bus voltage is too low.		
	Fault code 55	Output voltage is unbalanced.	to repair center.	

## 9 Appendix: Approximate Back-up Time Table

Model	Load (W)	Backup Time @ 48Vdc 100Ah (min)	Backup Time @ 48Vdc 200Ah (min)
	500	613	1288
	1000	268	613
	1500	158	402
	2000	111	271
	2500	90	215
	3200	76	182
PV 9200	3500	65	141
PV 12200	4000	50	112
	4500	44	100
	5000	40	90
	6200	36	80
	7200	32	70
	8200	28	60
	9200	24	50
	10200	20	40

**Note:**1.Backup time depends on the quality of the battery, age of battery and type of battery. Specifications of batteries may vary depending on different manufacturers.

<sup>2.</sup> The final interpretation right of this product belongs to the company.

技术要求:单页尺寸142\*210**mm**; 材质:封面105g铜版纸,内页80g书写纸; 料号打于后封面左下角;

注:此技术要求不用印刷